

PIXEL

Indoor Rollator

User's manual



REHASENSE



CE

more than mobility

1 General Information

Dear Customer,

This user manual contains a description of the medical device and important guidelines to ensure correct and safe use of the product. It is important to read this manual carefully prior to use. It is especially important to read the safety requirements and follow these.

REHASENSE continuously develops its products and reserves the right to change the specifications and functions of products without notice.

If you have any queries please contact your dealer or **Rehasense** directly. Contact information is located on the last page of this manual.

2 Intended usage, Indications & Contra indications

Intended usage: The rollator has been designed as a tool to assist walking for people who have mobility problems, for example with standing or walking independently. Thanks to this rollator these people can stand and walk easily and they can fulfil most of their daily tasks and routines without assistance from others. Any other usage is prohibited. The device is designed for indoor use only.

Indications: The device is specifically designed for individuals who, due to a wide variety of possible health problems, require additional stable support during walking.

Contraindications: The device must not be used outdoor, it shouldn't be used by users who have serious problems with body balance or whose muscle strength is too low to be able to stand and walk, even with the extra support of a rollator. The need and possibility of usage of a rollator by the user should always be assessed and indicated by a doctor or physiotherapist.

3 Delivery & general product description

The rollators are supplied in boxes and come folded, for easier transportation.

The contents are:

- 1 complete folded rollator incl. basket
- 1 removable tray
- 1 handy netbag
- 1 user's manual

Pixel is a four wheel, light weight rollator with a foldable frame. The product is made of aluminium, so it is very light and easy to store or transport. The rollator offers great manoeuvrability, stability and its push handle is height adjustable for a good user fit. The product consists of a powder coated foldable structure frame made of aluminum tubing and. It is also equipped with a fabric shopping bag and plastic tray which allows the user to carry small items. The rollator is equipped with 6 inch wheels for indoor use.

4 Security requirements

Make sure that this users manual is read by all people who use the device. The manufacturer does not take any responsibility for damages and/or injuries caused by the fact that the user's manual has not been followed.



Limitations for usage


- The device must not be loaded with more than 110 kg.

- The device's bag has a load limitation of 5 kg.
- The device is designed to be used indoor only and on flat, smooth surfaces.
- The device is not intended to seat on it.
- The brakes **MUST** be in the locked position **BEFORE** leaving the rollator unattended.



Avoiding accidents

- Use the device only for the purpose it is intended for.
- Use the device only in good technical condition.
- Avoid making constructive changes to the device, unless you have the manufacturer's written acceptance for such modifications.
- During different adjustments which are possible on the device, the user must take care not to trap their fingers or other body parts between two moving elements of the device
- The device must only be used on a stable surfaces.
- All wheels **MUST** be in contact with the floor at **ALL TIMES** during use. This will ensure the rollator is properly balanced and should avoid accidents.
- When using the rollator in a stationary position the hand brakes **MUST** be locked.



Be careful when you see this symbol on the device. Fingers or other body parts of a user and/or assistant can be trapped between the device's parts during folding, unfolding or adjusting of the device. Be extremely careful when adjusting the device. Observe the dimensions of gaps between the device's elements to avoid trapping your fingers or other body parts.

5 Product details



6 Usage


Looking at the picture above the device should be prepared for use in an instinctive way. However we recommend you follow the steps below:

Initial Check

- Take the device out of the box and check (using the picture above) that nothing is missing. If you discover at this stage that some part is missing or damaged do not continue to assemble the product. Contact your supplier of the product right away.

Opening of the rollator

- Hold the push handle in both hands in front of you so the rear wheels are on the floor. Push it down so the frame opens all the way.
- Find the red frame locking button on the basket frame. Lock it on the main frame until you hear a “click” sound of the locking mechanism.




- Try to pull the frame parts back up together to fold the frame. If this is impossible to do the frame is opened and secured correctly. See the OPEN position in the picture above.



- After unfolding or assembling the rollator always ensure that the frame halves are securely locked so that the frame does not move anymore.
- Always ensure that push handle is securely locked in the main support tube with the two locking knobs to prevent the accidental sliding in of the push handle tubes when forced.
- Always test to see that accessories are properly and safely locked in place BEFORE using.
- Failure to follow these warnings can result in personal injury.

Folding

- Push the red locking button which connects the basket frame with the main frame.
- Lift the bag's frame to pull the main frame halves together and to fold the rollator.



Adjusting the height of the push handle

- Release the handle's 2 locking knobs.
- Make adjustments to your desired height.
- Tighten the 2 knobs.



- *Both sides of the push handle should be adjusted to the same height.*
- *The correctly adjusted handle should be at the height of the user's hips.*

Using the hand brakes

- TO STOP THE ROLLATOR simply pull the brake handle up towards the hand grip.
- TO REMAIN STATIONARY hold the brake handle in the "UP" position.
- TO START MOVING release the brake handle. It will drop down automatically and the brakes will be released.



- *You should always engage the brakes when you don't plan to move the device.*
- *Never leave the device unattended without the brakes engaged!*
- *Never leave the device on slopes without the breaks engaged!*

Locking/Unlocking the hand brakes

- To lock the brakes push the brake handle down until you can hear the "click" sound.
- To unlock the brakes pull the brake handle up until you feel wheels free to roll.



- *When using the rollator in a stationary position, the hand brakes MUST always be locked.*

7 Cleaning

General:

- Clean the device regularly and keep it clean.
- Lighter dirt and dust can be removed with a wet cloth.
- Larger parts of dirt can be removed with a non-corroding, mild washing agent and warm water.
- Do not use harsh abrasives or bleach based cleaners, as this may cause damage or discoloration.
- Dry parts with a soft cloth.

Wheels:

- Clean wheels with warm water and a mild cleanser. Dry with a clean rag.
- Lubricate with multi-purpose oil periodically or if wheels begin to squeak.

8 Label

The product label is placed on one of the bottom tubes of the cross frame. It includes important information about the product: name, serial number, production date, item number, shopping bag's max load, product width, size and manufacturer's data. The label should be never removed from the device.

9 Technical data

Max. load	110 kg
Max. load of the bag	5 kg
Total weight with shopping bag	5,2 kg
Length opened	65 cm
Height folded (lowest)	91 cm
Width	54 cm
Length folded	27 cm
Height of hand grip (adjustable)	86 – 97 cm
Brakes	1 maneuver brake on 2 rear wheels with parking function
Wheels (diameter x width)	4x 150 x 27 mm – Black SOFT PU tire

10 Transport description

The rollator is a product easy to fold, making it convenient for transportation. If it is necessary to transport it we recommend to fold it as stated in the description above. The rollator should be transported in a way that it is stable and there is no risk of sudden and dangerous movements of the transported device.

11 Maintenance

- Ensure that every part of the rollator is secure at ALL times.
- Check all screws for tightness. If not, tighten if necessary.
- Replace any broken, damaged or worn items immediately.

12 Reuse

The walker is suitable for re-use. Before passing on to another user it must be subject to an inspection by the specialist dealer.

The following points have to be checked:

- Visual inspection of the frame
- Secure seating of nuts and bolts
- Condition of the plastic elements
- Condition of wheels and ball bearings
- Effectiveness and condition of the brakes

When one of the parts is damaged or broken it must be replaced by a new. It is recommended to replace the wheels whenever a change. All loose bolts and nuts must be tightened. The product must be thoroughly cleaned and disinfected prior to reuse.

WARNING! It is forbidden to re-use the rollator when the frame is bent or broken.

The instruction manual must accompany the rollator with every change.

13 How to dispose the product

The device should not be disposed with normal garbage. It should be delivered to the disposal station for re-use or recycling.

14 Warranty

The manufacturer offers a 2 year guarantee for errors in production. The guarantee is not valid by miss-intended use of the product.

In case of technical problems please contact your dealer.

You can also contact Rehasense® directly.

Dealer

Rehasense® Europe

Manufacturer

Rehasense Sp. z o.o.

Sulejowska 45
97-300 Piotrków Trybunalski
Poland

Rehasense Deutschland

Briener Strasse 25
47533 Kleve
Deutschland



REHASENSE

www.rehasense.com

info@rehasense.com